

C-999



- 1^e = Demontage Quadrant
- 2^e = Remove spie.
- 3^e = Demontage Holding ring
- 4^e = lower the rudder.
- 5^e = Replace both O-rings in top and middle bearing

